# **Bus Bar Contact**

# Assembly Instructions SB® 120

## **Bus Bar Contact Assembly Instructions**


- 1. Insert the contact into the D-shaped mounting hole in the bus bar.
- Tighten the lock nut provided until the contact is locked securely in place (approximately 12 in-lbs). Do <u>not grip nose</u> of contact while tightening.
- 3. Slide the connector housing over the contacts until the noses of both contacts snap firmly over the springs in the housing.
- 4. The bus bar connector is now secure and ready for use.

Panel Layout				
	-J-	-K-	-L-	-M-
inches	.93	.83(min)	.290	.250
mm	23.6	21.1(min)	7.37	6.35



SB Housing

Bus-bar



#### WARNING

UTMOST CAUTION SHOULD BE USED WHEN WORKING ON LIVE CONNECTOR CONTACTS

### **TRADEMARKS**

"SB" and "Anderson Power Products" are registered U.S. and foreign trademarks of Anderson Power Products.



HEADQUARTERS: 13 Pratts Junction Road, P.O. Box 579, Sterling, MA 01564 T:978-422-3600 F:978-422-3700 EUROPE: Rathealy Road, Fermoy Co. Cork, Ireland T:353-(0)25-32277 F:353-(0)25-32296

ASIA/PACIFIC: IDEAL Anderson Asia Pacific Ltd., Unit 922-928 Topsail Plaza, 11 On Sum Street, Shatin N.T., Hong Kong T:852-2636-0836 F:852-2635-9036 www.andersonpower.com

1S6442 Rev 05 ASM-BBSB120